

RÜCKENPOLSTER

backrest pad | coussin de dossier moto | almohadilla de respaldo | cuscino schienale

Art.Nr. : 30671-700



Untergrund vor dem Bekleben entfetten.
Degrease the surface before application.
Dégraissier la surface avant l'application.

